

Care instructions - ALU-mats

ALU-mats OPEN - entrance mats with aluminium profiles

With 3-10 mm gap between the profiles.

Daily-/weekly cleaning - depending on traffic and pollution



1. Vacuum cleaning.

2. Remove large dirt particles and stones between the profiles before rolling the carpet.

3. Roll up the mat to sweep/vacuum up dirt that has fallen between the profiles. Make sure that the well is clean and that no gravel gets under the profiles when the mat is rolled back. This will damage the profiles when they are loaded from above.

Extra cleaning



1. First, carry out "daily cleaning".

2. Followed by carpet cleaning, e.g. with a Kärcher BR 30/4 C Advance scrubber-dryer.

ALU-mats DENSE - entrance mats with aluminium profiles

WITHOUT gaps between the profiles.

Daily-/weekly cleaning - depending on traffic and pollution



1. Vacuum cleaning.

This type of mat with dense profiles does not let dirt and grit through and cannot be rolled.

TIP!

If, for example, chewing gum is stuck in the needle felt, use cooling spray on the stain to easily remove the gum.

Extra cleaning



1. First, carry out "daily cleaning".

2. Followed by carpet cleaning, e.g. with a Kärcher BR 30/4 C Advance scrubber-dryer.